


mistral

Air Purifier with Remote Control MAPF530






AIR PURIFIER


Please read this instruction manual thoroughly
before operating and keep it for future reference

IMPORTANT SAFETY INSTRUCTIONS

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been dropped or damaged in any manner. If the power cord is damaged, it must be replaced by the Service Centre to avoid a hazard.
- When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury.
- Do not immerse appliance, cord or plug in water or other liquid.
- Unplug from the outlet when not in use and before cleaning.
- Do not unplug the appliance by pulling on the cord.
- Use the accessories from the appliance only, as other accessories not from the appliance may cause fire, electric shock or injury.
- Indoor and household use only. Do not place in the following places:
 - Do not place in direct sunlight or have the air outlet facing the sunlight and any heated places as it may cause deformation, deterioration, discoloration, and failure.
 - To prevent electromagnetic disturbance, be sure to place the air purifier at a distance of 1m or more from TVs and or radios.
 - Change the plug to a different outlet if there is any distortions.
 - Place the air purifier on a flat floor when indoors as pollen, dust, etc are likely to fall near to the ground.
 - To properly circulate the air in the room, be sure not to block the air inlet and outlet. The air purifier should be placed about 30cm or more from the left and right of any walls, furniture, curtains, etc.
 - Do not place objects on the air purifier, magnets or metal objects, or place items on top of the appliance as it may cause damage to the appliance.
 - Locations that are hot, humid, or wet, such as bathrooms (air purifiers may cause electric shock or fire due to electric leakage.) a place where the kitchen emits soot. Do not use air purifiers in indoors with incense-based.



- Do not insert the fingers or objects into the air inlets or air outlets to prevent physical injuries or malfunction.
- Do not place near a humidifier as it may affect the PM 2.5 detection of the appliance, and both should maintain a certain distance.
- Do not disassemble or modify the air purifier yourself to avoid accidents.
- Do not use the air purifier near gas appliances, heating devices, or stove.
- Do not use in a wet or hot environment such as a bathroom, toilet or kitchen.



Insecticide

- Chemical residues may accumulate in the machine and then be released from the air outlet to endanger your health.
- After using the insecticide, allow the room to be thoroughly ventilated before using the air purifier.
- It is not recommended to use an air purifier when burning incense or mosquito coils, otherwise the filter of the air purifier will leave an odor.


Warning

- Turn off the power of the air purifier immediately and contact the Service Centre when any of the following occurs:
 - Abnormal sound or vibration during use.
 - Strange smell, hot, and or burnt odor.
 - If the power plug is dusty and or has moisture on it.
 - If the air purifier has not been used for a while.
 - Before any maintenance and or cleaning.


PRODUCT TECHNICAL PARAMETERS

MODEL	RATED VOLTAGE	RATED POWER	CADR	AREA
MAPF530	110-240V, 50/60Hz	50W	530 m ³ /hr	36-62 m ²


INTRODUCTION OF PARTS




Remote Control



Control Panel




Display Panel



CONTROLS AND OPERATIONS

Installation


1. Remove the filter screen from the plastic bag.
2. Insert the filter screen into the bottom of the air purifier.
3. Turn the bottom cover clockwise and tighten it.



Remove the filter screen

1. Turn the bottom cover counterclockwise.
2. Pull out the filter screen.

Note: Always remove the plastic bag from the filter screen before use.



How To Use

Power

- When the air purifier is switched on, there will be a beep sound before entering standby mode.
- Press the power button to start and it entered into auto operating mode, switch on the negative ion function and the air purifier will start in speed 2.



Speed

- Press the speed button, the display screen displays 1, 2, 3, 4, or 5 (cycle), then the air purifier current speed, and adjust the speed according to the gear change.



Mode

- Press the mode button to switch between auto, turbo, and sleep mode.



Timer



- When the filter screen icon prompts replacement, in case of timing, press this button long to cancel the timing function first, and press it again for the second time to reset the filter screen prompt function. If there is no timing function, press this button long to reset the filter screen replacement prompt function.
- Touch the timer to display the 0-8 hour cycle.
- After the timer function is turned on, the icon will light up "H".
- Press and hold the timer button for two seconds to cancel the timer or touch the timer button and the number "0" appears to cancel the timer.

Reset

- When the machine reaches 1,500 hours, the button icon flashes white slowly, prompts to change the filter screen, press the reset key for 3 seconds and reset the replacement prompt.



Sterilize

- Press this button to switch on/off the function of UV and ecological super-energy ions.
- When the function is turned on, "UV" and "SE" icons are highlighted, and the icons do not illuminate when the function is turned off.



Lock

- Press this button for 3 seconds to enter the child lock function.
- After the child lock function is started, the buttons on the machine will not be operated.
- Press this key for 3 seconds to unlock before operation.




Air Quality Chart

24 Hour PM 2.5 Levels (µg/m3)		
PM 2.5	Air Quality Index	Air Quality Indicator
0 - 12.0	Good 0 - 50	Green
12.1 - 35.4	Moderate 51 - 100	
35.5 - 55.4	Unhealthy for Sensitive Groups 101 - 150	Yellow
55.5 - 150.4	Unhealthy 151 - 200	
150.5 - 500+	Extreme Unhealthy 201 - 500	Red

How to use the aroma diffuser attachment

1. Drip the essential oil onto the circular foam.
2. Place the foam into the diffuser holder.
3. Close the diffuser lid.
4. Clip the diffuser onto the appliance.



CLEANING AND MAINTENANCE

Filter Screen Maintenance and Repair

- Anti-virus Hepa and Carbon filter will need to be changed after 1,500 hours of usage, the button icon flashes white slowly as a prompt to change the filter.
- Press the reset button “” for 3 sec to reset the replacement prompt.
- Reset icon flashes slowly after 500 hours and change to long light in case the is no reset.
- Sleep mode does not prompt to change the filter screen.
- Filter screen replacement is prompted after the end of sleep mode. (Reset is the prompt function of filter screen replacement. It is not the current accumulated time).
- Put the filter screen in a ventilated place so that harmful gases and bacteria on the filter screen surface can be volatilized.
- Do not put it in too strong sunlight.
- Do not wash the filter screen with water.



Warm tips

- Before cleaning and maintenance, the power plug must be unplugged.
- Do not operate under the condition that the filter screen has been removed (the machine should be no dust removal effect and suction of dust may cause device failure).
- When it is idle for a long time, please unplug the power plug (it still consumes electricity in standby mode).
- The replacement cycle of the filter screen may be shortened depending on the place of use and the use method (e.g. households with high smokers or areas with severe air pollution).
- If the filter effect is not obvious, please replace the filter screen in time.
- When changing the filter screen, please turn off the power supply first.

TROUBLESHOOTING

Problem	Cause of Issue	Solution
The power is switched on but there is no response.	The power cord is not plugged in properly.	Be sure that the power cord is properly plugged in.
	The filter screen is not placed in the air purifier correctly.	Be sure to install the filter screen correctly.
The air purifier is producing an odd smell.	The filter screen may be dirty.	Carefully clean the filter screen.
	The filter screen has not been replaced for awhile.	Replace the filter screen.
The filter screen icon is switched on.	The filter screen icon switched on indicates that the filter screen needs to be changed.	Replaced the filter screen before resetting the timer.